

TM-40 SUPPLEMENTAL INSTRUCTIONS

The TM-40 Moden is your link to communicating with other computers, terminals, and time-sharing systems.

In order to use the TM-40 Modem with the Imagination Nachine, you will need the following equipment.

- 1. The Imagination Machine 2. 85-1 (Suilding Block Expansion Box w/SI232 Interface)
- Computer to Nodem Cable
  Term I Nodem Program on cassette

## System dookup:

- 1. Connect the Inagination Machine to the expansion box as per
- Insert SI232 Cartridge into expansion box, and SET BAUD RATE TO 300 BAUD.
- Set switches on modem as follows:
  - A. FD-TST-HD: Set to FD (full duplex)
  - B. OR-OFF-AN: Set to OR (originate call). Set this mode to AN if you will be answering.
- Connect the RS232 to modes connector to the serial interface on one side and to modes connector on the other (this is a bidirectional cable and can be connected on either side).

## TERM I:

When this program is leaded and run, it allows the Inspination Machine to act as a terminal (instead of a computer). The kayboard is summed, sent out via the SIJJZ (to a modem) and echoed onto the screen. Imputs from the SIJJZ are put on the screen.

## Operation:

Load TERM I Modem Program into Insgination Hackine. When OK appears, type RUN. A red ownsor should appear. At this point you are ready to mather call to another terminal or time-sharing system (OR Mode), or to accept a call from another source (RN Mode).

Refer to the star modes operators' manual for further information